Noise 3

Multiple Choice Quiz

TI Precision Labs – Op Amps



🔱 Texas Instruments

- 1. Which type of amplifier has the lowest current noise?
- a. CMOS
- b. Bipolar

2. (T/F) Current noise is related to an amplifiers quiescent current.

- a. True
- b. False

3. (T/F) Voltage noise is related to an amplifiers quiescent current.

- a. True
- b. False

4. Amplifiers with high quiescent current have _____.

- a. High voltage noise.
- b. Low voltage noise.
- c. Quiescent current has no relationship to noise.



- 5. Why isn't there an exact relationship between rms and peak-to-peak?
- a. Because noise constantly changes.
- b. Because a dc offset can affect the rms value.
- c. The Gaussian curve tails introduce a small probability of a peak outside the 6 sigma limit.



Noise 3

Multiple Choice Quiz: Solutions TI Precision Labs – Op Amps



Texas Instruments

- 1. Which type of amplifier has the lowest current noise?
- a. CMOS
- b. Bipolar
- 2. (T/F) Current noise is related to an amplifiers quiescent current.
- a. True
- b. False
- 3. (T/F) Voltage noise is related to an amplifiers quiescent current.
- a. True
- b. False
- 4. Amplifiers with high quiescent current have _____.
- a. High voltage noise.
- b. Low voltage noise.
- c. Quiescent current has no relationship to noise.



- 5. Why isn't there an exact relationship between rms and peak-to-peak?
- a. Because noise constantly changes.
- b. Because a dc offset can affect the rms value.
- c. The Gaussian curve tails introduce a small probability of a peak outside the 6 sigma limit.

